



INSTALLATION INSTRUCTIONS

- 1) DRAWERS-IN-SHELVING EXTERNAL LOCKBARS CAN ONLY BE MOUNTED TO THE T-POSTS AFTER ALL SHELVING, FRAMES AND DRAWERS HAVE BEEN INSTALLED.
- 2) LOCATE EXTERNAL LOCKBAR AS SHOWN ON THE LEFT SIDE OF THE DRAWERS. WITH A #27 (Ø 0.144) DRILL BIT, USING THE HOLES ON THE HINGE OF THE EXTERNAL LOCKBAR AS A GUIDE, DRILL HOLES THROUGH THE T-POST.
- 3) SECURE THE EXTERNAL LOCKBAR TO THE T-POST USING THE SUPPLIED THREAD CUTTING SCREWS.

LYON

P.O. Box 671
 AURORA, IL 60507-0671
 PHONE: 630-892-8841
 FAX: 800-867-4681

NOTICE: THIS IS A CONFIDENTIAL DISCOUNT LOANED BY LYON WORKSPACE FOR REFERENCE PURPOSES ONLY

DATE	DRAWN BY	CHECKED BY
01-31-12	JR	DWV
DESCRIPTION		

INSTALLATION
 DIS ELB
 MDC

SHEET	DRAWING NUMBER	REV
-	SS1444	1