



ASSEMBLY INSTRUCTIONS

DRILL TWO (2) 0.166 DIAMETER HOLES ON THE SIDE OF THE CABINET WHICH IS TO ACCEPT ATTACHMENT OF THE STRINGER PER DRILL PATTERN SHOWN ABOVE.

ATTACH STRINGER TO CABINET AND PANEL LEG AS SHOWN WITH SUPPLIED #10-24 THREAD CUTTING SCREWS. FOUR (4) SCREWS WILL BE REQUIRED FOR ALL CABINETS.



#10-24 THREAD CUTTING SCREW

SUPPLIED HARDWARE



P.O. Box 671
AURORA, IL 60507-0671
PHONE: 630-892-8941
FAX: 800-367-6681

NOTICE: THIS IS A CONFIDENTIAL DISCUSSION, LOANED BY LYON WORKSPACE FOR REFERENCE PURPOSES ONLY.

DATE 07-19-12
DRAWN BY JR
CHECKED BY DMV

DESCRIPTION

INSTALLATION
STRINGER
MDC

SHEET	1	REV	1
DRAWING NUMBER	SS1873		